

FireFly™

TACTICAL PA SYSTEM



Owner's Manual and Operation Guide

Technomad LLP • Made in USA
military.technomad.com • 800 464 7757
military@technomad.com

Technomad FireFly™ Tactical Micro PA System

Owner's Manual and Operation Guide

Overview

The FireFly is a self-casing, portable PA unit designed to meet the requirements of a man pack PA system while offering Technomad's unsurpassed combination of audio quality, product flexibility and ruggedness. Fully weatherproof, the FireFly can easily be transported and set up by one person. Compact and rugged, the FireFly can easily fit in an ALICE pack or similar large rucksack. A molded in stand-mount socket on the bottom of the unit and inserts on the sides for yoke mounting give the FireFly a range of deployment options. With a powerful compression driver coupled with a highly efficient horn, the FireFly is capable of producing highly intelligible audio at 125 dB SPL.

The FireFly is highly expandable with an available expansion bay for use with Technomad's SuperConductor™ MP3 player/recorder, a CD player module, a second wireless microphone or a Link Kit interface, including wireless, Ethernet and twisted pair configurations. Extended operation time is available through either internal or external battery pack options. Whether you need a self-contained, complete PA unit for field deployment or to expand or build an existing PA system with additional, compact output units, the FireFly can meet your requirements.

Physical Construction

The FireFly has a single piece rotomolded cabinet, making the unit extremely durable. When the clear hatch covering the upper control surface is closed and latched, the unit is rated IP56. The hatch should not be left open in rain or snow conditions. The front lid is designed to be removed during operation. Similarly, the access panel for the wireless microphone programming buttons should not be opened in rain or snow conditions.

Standard Features

- Compact, rugged design
- Handheld wireless microphone system
- Expansion bay for MP3 player/recorder, CD player, ethernet, twisted pair, or wireless interface
- Storage pouch in lid for power cords, microphone
- Stand-mount socket on bottom
- Threaded inserts for yoke mounting
- Low profile handle for easy carrying
- Microphone input
- Line audio input
- Aux. speaker output
- AC power input (120-240 VAC)
- DC power input (12-24 VDC)
- 4 hour battery operation, 20 hour stand-by capacity

FireFly rear panel overview

1) Expansion Bay Available installable options include SuperConductor mp3 player/recorder, CD player, second wireless microphone system, ethernet interface, wireless interface, twisted pair interface.

2) Microphone input

3) Line level audio input

4) Level controls for four audio sources.

5) Power source LED

Red = Internal battery
Green = external DC
Blue = external AC

6) Battery charger LED

Green = full charge
Blue = charging
Off = charger off

7) Microphone access panel

This panel can be removed to access microphone controls for pairing handheld transmitter or changing the broadcast channel.

8) Aux. speaker output

Allows a FireFly expansion unit to be powered from FireFly


9) AC power connector

Harwin 10SL-3P.
120-240VAC

10) On/Off switch

11) DC power connector

Harwin 10SL-4P.
12-24VDC



Note: FireFly is shown without clear protective hatch for audio control surface for clarity.

Basic Operation

The FireFly can be run from the internal battery pack, external 120-240VAC power or external 12-24VDC power. The FireFly is designed to automatically detect the preferred power source and to use that source on start-up. The default source is external AC, followed by external DC then the internal battery back. When the unit is first powered on, the unit will cycle through the power options to determine which source will be used. If the unit is running from a source that becomes unavailable, then it will automatically switch over to the next available default power source. If the unit is running from the internal battery and the battery gets depleted then the unit will simply shut off.

After the unit is operational, you can set the volume level for whatever audio source you are using by adjusting the appropriate level control knob on the upper panel of the FireFly. You can use all four audio inputs simultaneously.

Clip light - this LED signals when the inputs to the FireFly are being overdriven. While it is acceptable for the Clip LED to flicker during operation, the LED should not stay constantly lit. If the LED is fully lit, all active inputs levels should be reduced until the light is occasionally flickering. The audio mixer of the FireFly does incorporate a limiter circuit to reduce clipping.

Wireless Microphone operation

The wireless microphone system integrated into the FireFly ships with the handheld transmitter paired to the receiver inside the unit. To start using the wireless system, you can simply take the handheld unit out of the storage pouch inside the lid and press the power/mute button until the green light on the mic is on. To mute the microphone, press the button once. When muted, the indicator on the handheld transmitter should be red. To shut the microphone off, simply press and hold the button until the light goes off.

If you need to change the channel that the system is using, you will need to access the microphone receiver settings. First, remove the microphone access panel by undoing the two knurled knobs. You can now see the programming panel of the unit. Press and release the channel button. This will scan for an available channel and select that channel. Next, turn on the handheld unit and remove the battery cover by unscrewing the lower part of the handheld transmitter. Point the base of the unit towards the microphone receiver and press and hold the sync button on the receiver. Hold the button until the red lights on the receiver and handheld unit stop flashing. The receiver ready light should now be lit and the system should be set to operate on the new channel. Re-attach the battery cover on the handheld unit.

The operational range of the wireless transmitter is approximately 300'.

Battery System

The FireFly has a 5AH NiMH battery which is charged by the integrated battery charger. Depending on the program material being reproduced by the FireFly, the battery should provide up to four hours of operational time. If the battery has become fully discharged, it may be necessary to power the unit off for 5-10 minute to allow the battery pack to recover sufficiently for the battery

charger to optimally recharge it. The battery charger is a smart charger design, meaning that it can quickly charge the battery pack to full charge within 3-4 hours without harming the cells. The unit does need to be on in order for the battery to charge. The FireFly includes a LVD circuit to protect the battery from being excessively depleted in the event that the unit is left on indefinitely.

IMPORTANT: NiMH batteries can continue to lose charge even when the unit is off. For best performance, be sure to charge your FireFly fully every three weeks.

Troubleshooting

Problem	Solution
The unit will not power on from battery pack	Check that the battery pack is charged by connecting the FireFly to an AC power source.
No sound is being produced by the unit.	<ul style="list-style-type: none"> • Check that a working audio source is being used. • Check that the appropriate level control has been turned up. If you are uncertain if a source is working, set the level control to 12 o'clock to until you have the source working. • If using the wireless system, is the handheld transmitter on? Check that the handheld unit is not muted.
The unit is temporarily shutting off when used.	Check that the input being used is not being overdriven. The FireFly audio amplifier incorporates clipping protection and will temporarily shut down. Simply turn down the level control for that source to prevent this problem from reoccurring
The unit is not charging properly.	Shut the unit off completely and let sit for 15 minutes, then reconnect to AC power to re-charge the battery pack.
Microphone is causing feedback.	Move behind the loudspeakers when speaking, if possible. If in front of the loudspeakers keep the 'live' end of the mic (the part you speak into) pointing AWAY from the loud-speaker.) Switch the mic off when you're not speaking through it.

Reset Function: The FireFly can be reset by pressing and holding the power button for a full 10 seconds then releasing the button. This will reboot the internal controller board and may resolve charging or power issues.

Expansion Bay Modules (one module can be installed per system):

SuperConductor MP3 player/recorder
Wireless Microphone, lapel system
Twisted Pair Link Kit
Wireless Link Kit

CD player
Wireless Microphone, handheld system
Ethernet Link Kit

Available Accessories/Options:

Optional color: olive drab, desert sand, white, gray
FireFly Expansion Unit (aux. passive loudspeaker)
Yoke mount

External battery pack (18AH SLA battery)
Tripod Stand
DC power cord